

# Adjustments

The headband and microphone boom can be bent to achieve best comfort and sound quality. You can't break them!

## ADJUSTING THE HEADBAND

1. Using both hands, flex the headband in or out until the cushion(s) rests with almost no pressure on your ear.
2. Slide the headband up or down until it rests on the top of your head and the cushion(s) is centered against your ear.



## ADJUSTING THE MICROPHONE BOOM

The microphone boom is flexible, so you can bend and rotate it for comfort and best transmission. Adjust the position of the microphone so that it is one inch away from your lips and one inch below. Avoid positioning the microphone directly in the path of your breath.

**Important:** Make sure that the side of the microphone with the foam screen is pointed toward your mouth.



## ATTACHING THE CLOTHING CLIP

After adjusting your headset, attach the clothing clip, leaving enough slack for comfortable head movement.

