

6.0 INSTALLATION NOTES AND ASSEMBLY INSTRUCTIONS

- 6.1 Using a 301-037 security tool (sold separately), loosen and remove the security screws.
- 6.2 The security tool is for a standard 5/32" button head screw generally used on the framework of the phone booths.
- 6.3 Run the inside station wire into the housing enclosure and terminate on the RJ11C terminal block inside.
- 6.4 The use of a gas tube, or carbon station protector is recommended. The station ground should not exceed 50 ohms.
- 6.5 Plug the modular line cord from the faceplate assembly into the RJ11C terminal block.
- 6.6 Dress the line cable away from the security screws and seat the faceplate into the housing enclosure.
- 6.7 Secure the faceplate assembly by tightening the security screws.

*****WARNING*****

- A. Never install telephone wiring during a lightning storm.
- B. Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- C. Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- D. Use caution when installing or modifying telephone lines.

