

5.0 INSTALLATION NOTES AND ASSEMBLY INSTRUCTIONS

- 5.1 The SSP-371-F is designed to be mounted inside any apparatus box with dimensions of 6 7/8" W x 9 3/4" H x 3" D or greater. CEECO part number 371-011 is an apparatus box, which is well suited for this purpose. Four mounting holes are required inside the box. If the holes are not tapped, then self-tapping screws should be used when mounting the panel. It is best to use the security screws, which do require tapped mounting holes.
- 5.2 Mount the two mounting support brackets provided to the apparatus box being used. Route the inside station wire and terminate to an RJ11C modular jack or terminal block.
- 5.3 The use of a gas tube station protector is recommended. The station ground should not exceed 50 ohms.
- 5.4 Plug the modular line cord from the telephone assembly into the RJ11C modular jack or terminal block. Dress the line cable away from the mounting holes. Install the telephone assembly by placing it into its mounting box and securing it with the four security screws.

*****WARNING*****

- A. **Never install telephone lines during a lightning storm.**
- B. **Never install telephone jacks in wet locations, unless the jack is Specifically designed for wet locations.**
- C. **Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.**
- D. **Use caution when installing or modifying telephone lines.**

