

5.0 INSTALLATION NOTES AND ASSEMBLY INSTRUCTIONS

- 5.1 Using a 301-037 security tool (sold separately), loosen and remove the security screw.
- 5.2 The security tool is for a standard 5/32" button head screw generally used on the framework of the phone booths.
- 5.3 Separate the cover assembly from the backplate assembly.
- 5.4 The backplate assembly may be installed on any standard backboard.
- 5.5 Run the inside station wire through the backplate assembly and terminate on to the RJ11C terminal block on the backplate.
- 5.6 The use of a gas tube station protector is recommended. The station ground should not exceed 50 ohms.
- 5.7 Plug the modular line cord from the cover assembly into the RJ11C terminal block.
- 5.8 Dress the line cable away from the security screw and install the cover assembly by inserting the tabs into the slots on top of the backplate.
- 5.9 Secure the cover assembly by tightening the security screw.

*****WARNING*****

- A. Never install telephone wiring during a lightning storm.
- B. Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- C. Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- D. Use caution when installing or modifying telephone lines.

