


work faster.

The GN 9120 Buttons Explained.

More freedom to work your way: Three simple buttons.



Multifunction button (B/center button)

The multifunction button serves several functions, depending on how long the button is pressed for.

Functions	Press Momentarily	Press for 2 seconds	Press for 6 seconds
Mute	x		
Un-mute	x		
Answer/make call	x		
End Call		x	
Tone control adjustment			x
Conference mode	x		

Functionality of the + and – buttons (A & C buttons)

Functions	Press Momentarily	Press for 2 seconds
Volume +	x	
Volume –	x	
Transmit volume adjustment		x (+/- simultaneously)

Audible Indicators (sounds in your headset)

There are a number of sounds that your headset will make to indicate various connection status.

Functions

Out of Range	Tone in headset every 10 seconds
Mute	Tone in headset every 15 seconds
Low Battery	Tone in headset every 20 seconds
Incoming Call	Tone in headset with RHL use

If you move out of range, a tone will sound in your headset. Calls in progress are not disconnected but will in effect be put on hold. When you move back within range, your communication will be re-established.