## cessories


ase read "Important Information" on page 11 before use. It is important to d and understand all instructions.


## Accessories (Included)

AC AdaptorTwo (PQLV19)	☐ Charger One	☐ BatteryOne (N4HHGMB00005 or HHR-P103)
	Part no. Charcoal: PSLP1321Z White: PSLP1321ZW	
Handset Clip One	☐ Belt Holder One	☐ Battery Cover One
t no. Charcoal: PSKE1084Z4 Vhite: PSKE1084Z3	Part no. Charcoal: PSKE1040Z White: PSKE1040Z2	Part no. Charcoal: PSYNTD7896MR White: PSYND7896MWR
Telephone Cord One	☐ Screws and Washers	☐ Wall Mounting PlateOne
	© 0 0 0 0 0	Part no. Black: PSKL1032Z1
		White: PSKL1032Z3

## Location of Conti

## Handset





Indicator Status:

- On (Green)—Base unit is connected to PBX
- Flashing (Green)—Base unit is on, but not connected to PBX