




When connecting to a DirecTV® high definition system – a triple LNB, integrated dish, a dish with a multiswitch built in, etc. – you must set the orange dial labeled LNB to 22kHz!







Terrestrial can be off-air antenna, HD antenna, cable, cable modem, a modulated signal or anything transmitted on a frequency between 5 and 862 MHz.