


# Intercom Headsets Guide

## Complete Unit: Supra, Monaural NC

PART NUMBER	CONNECTOR	APPLICATION	QD TYPE
91008-01	NC4FX	Clearcom	Supra
91008-02	NC4MX	RTS	Supra
91008-03	NC5MX	RTS	Supra



## Complete Unit: Starset

PART NUMBER	CONNECTOR	APPLICATION	QD TYPE
91720-01	NC4FX	Clearcom	Supra
91720-02	NC4MX	RTS	Supra
91720-03	NC5MX	RTS	Supra



## Base Unit: Push To Talk

(for use with Dynamic Microphone Headsets listed below)\*

PART NUMBER	CONNECTOR	APPLICATION	QD TYPE
92187-01	NC4FX	Clearcom	Supra
92187-02	NC4MX	RTS	Supra
92187-03	NC5MX	RTS	Supra



## \*Headsets

PART NUMBER	CONNECTOR	QD TYPE
*91022-01	Supra Monaural NC	Supra
*91041-01	Supra Binaural NC	Supra
*90169-01	Starset	Supra

## Interconnect Cable: Connector to QD

PART NUMBER	CONNECTOR	APPLICATION	QD TYPE
90024-01	NC4FX	Clearcom	Supra
90025-02	NC4MX	RTS	Supra
90026-03	NC5MX	RTS	Supra



## Base Unit: Push To Talk, Amplified

(for use with H-Tops)

PART NUMBER	CONNECTOR (Tip/Ring/Sleeve Type)	QD TYPE
91927-10	267 connector, 10 foot cord	H
91927-15	267 connector, 15 foot cord	H
91927-25	267 connector, 25 foot cord	H

Sold by:



\*These headsets have dynamic microphones and are not interchangeable with H Style headset tops. As a result, the Supra QD is used to prevent wrong connections.

## Accessories

PART NUMBER	CONNECTOR	QD TYPE
92323-01	Mute Switch	Supra