

Intercom Headsets Guide

Complete Unit: Supra, Monaural NC

| PART NUMBER | CONNECTOR | APPLICATION | QD TYPE |
|-------------|-----------|-------------|---------|
| 91008-01 | NC4FX | Clearcom | Supra |
| 91008-02 | NC4MX | RTS | Supra |
| 91008-03 | NC5MX | RTS | Supra |



Complete Unit: Starset

| PART NUMBER | CONNECTOR | APPLICATION | QD TYPE |
|-------------|-----------|-------------|---------|
| 91720-01 | NC4FX | Clearcom | Supra |
| 91720-02 | NC4MX | RTS | Supra |
| 91720-03 | NC5MX | RTS | Supra |



Base Unit: Push To Talk

(for use with Dynamic Microphone Headsets listed below)*

| PART NUMBER | CONNECTOR | APPLICATION | QD TYPE |
|-------------|-----------|-------------|---------|
| 92187-01 | NC4FX | Clearcom | Supra |
| 92187-02 | NC4MX | RTS | Supra |
| 92187-03 | NC5MX | RTS | Supra |



*Headsets

| PART NUMBER | CONNECTOR | QD TYPE |
|-------------|-------------------|---------|
| *91022-01 | Supra Monaural NC | Supra |
| *91041-01 | Supra Binaural NC | Supra |
| *90169-01 | Starset | Supra |

Interconnect Cable: Connector to QD

| PART NUMBER | CONNECTOR | APPLICATION | QD TYPE |
|-------------|-----------|-------------|---------|
| 90024-01 | NC4FX | Clearcom | Supra |
| 90025-02 | NC4MX | RTS | Supra |
| 90026-03 | NC5MX | RTS | Supra |



Base Unit: Push To Talk, Amplified

(for use with H-Tops)

| PART NUMBER | CONNECTOR (Tip/Ring/Sleeve Type) | QD TYPE |
|-------------|----------------------------------|---------|
| 91927-10 | 267 connector, 10 foot cord | H |
| 91927-15 | 267 connector, 15 foot cord | H |
| 91927-25 | 267 connector, 25 foot cord | H |

Accessories

| PART NUMBER | CONNECTOR | QD TYPE |
|-------------|-------------|---------|
| 92323-01 | Mute Switch | Supra |

*These headsets have dynamic microphones and are not interchangeable with H Style headset tops. As a result, the Supra QD is used to prevent wrong connections.