

VICTORIA

• TUNEWRIER •

The Victoria Tunewriter records directly from the built-in Turntable, Cassette Player or from an Auxiliary Input onto CD-R/RW discs.



FEATURES

CD Recorder

- Front-loading drawer type CD Recorder / Player
- Supports CD-R/RW record and play
- Records Phono to CD, Cassette to CD, Aux to CD
- CD-DA, CD-R, CD-RW disc compatible
- Record Level Control and Record Level Indicator
- Up to 32-track CD music Memory

Turntable Section

- 3-Speed Belt-drive turntable (78, 33, and 45 RPM)
- Built-in Adapter for 45 RPM records
- Automatic tone arm return at end of play

Amplifier / Tuner Section

- Rotary Analog AM/FM radio tuner
- Rotary volume control

Cassette Player

- Side Slot Cassette with Single Play Function

General

- Two Full-range speakers deliver stereo sound
- LCD Display with Blue Backlight
- Headphone Jack
- Full Function Remote Control
- Function selector
- Paprika Wood Style Cabinet

Additional Specifications

- Auxiliary Audio input/output
- Output Power: 2 x 5W
- Power: 120V AC, 60Hz
- Dimensions: 21" x 13.4" x 11.6" (in closed position)



VICTORIA
• PHONOGRAPH •

WWW.VICTORIAPHONOGRAPH.COM