

## lyriQ Zone Expander with Integration - AU1023

Add audio to the Unity Home System. Create 16 independent zones of audio by connecting two Four Source, Eight-Zone Distribution Modules to the Integration Module.



## FEATURES

- No power supply required
- Convenient RJ45 connections
- Specifically designed for the Unity Home System

