

Pin and Sleeve

Watertight Devices Ordering Information

60 and 100 Ampere – North American Ratings

63 and 125 Ampere – International Ratings

| UL | SF | IP67 Suitability | Watertight Devices | | | | Back Boxes | | Replacement Interior Kits | | | | |
|-----|-------|---------------------|--------------------|------|--------------------|-------------|--------------|-------------|---------------------------|--------------|--------------------|-----------------------------|----------------|
| | | | Receptacle | Plug | Connector | Inlet | Non-Metallic | Metallic | Conn. Recept. | Plugs Inlets | | | |
| | | | | | | | | | | | Poles and Wires | Configuration Recep./ Conn. | Plug/ Inlet |
| 60 | 2P 3W | | | | 125 | HBL360R4W | HBL360P4W | HBL360C4W | HBL360B4W | BB60N | BB601W BB602W | IN360AF | IN360AM |
| | 2P 3W | | | | 250 | HBL360R6W | HBL360P6W | HBL360C6W | HBL360B6W | BB60N | BB601W BB602W | IN360BF | IN360BM† |
| | 2P 3W | | | | 480 | HBL360R7W | HBL360P7W | HBL360C7W | HBL360B7W | BB60N | BB601W BB602W | IN360BF | IN360BM† |
| | 3P 4W | | | | 125/250 | HBL460R12W | HBL460P12W | HBL460C12W | HBL460B12W | BB60N | BB601W BB602W | IN460CF | IN460CM |
| | 3P 4W | | | | 3Ø250 | HBL460R9W | HBL460P9W | HBL460C9W | HBL460B9W | BB60N | BB601W BB602W | IN460DF | IN460DM |
| | 3P 4W | | | | 3Ø480 | HBL460R7W | HBL460P7W | HBL460C7W | HBL460B7W | BB60N | BB601W BB602W | IN460DF | IN460DM |
| | 3P 4W | | | | 3Ø600 | HBL460R5W | HBL460P5W | HBL460C5W | HBL460B5W | BB60N | BB601W BB602W | IN460DF | IN460DM |
| | 4P 5W | | | | 3ØY120/208 | HBL560R9W | HBL560P9W | HBL560C9W | HBL560B9W | BB60N | BB601W BB602W | IN560EF | IN560EM† |
| | 4P 5W | | | | 3ØY277/480 | HBL560R7W | HBL560P7W | HBL560C7W | HBL560B7W | BB60N | BB601W BB602W | IN560EF | IN560EM† |
| | 4P 5W | | | | 3ØY347/600 | HBL560R5W | HBL560P5W | HBL560C5W | HBL560B5W | BB60N | BB601W BB602W | IN560EF | IN560EM† |
| 63 | 2P 3W | | | | 220-240 | HBL363R6W | HBL363P6W | HBL363C6W | HBL363B6W | BB60N | BB601W BB602W | IN360BFS | IN360BMS† |
| | 3P 4W | | | | 380-415 | HBL463R6W | HBL463P6W | HBL463C6W | HBL463B6W | BB60N | BB601W BB602W | IN460DFS | IN460DMS |
| | 4P 5W | | | | 220/380 240/415 | HBL563R6W | HBL563P6W | HBL563C6W | HBL563B6W | BB60N | BB601W BB602W | IN560EFS† | IN560EMS |
| 100 | 2P 3W | | | | 125 | HBL3100R4W | HBL3100P4W | HBL3100C4W | HBL3100B4W | BB100N | BB1001W BB1002W | IN3100AF | IN3100AM |
| | 2P 3W | | | | 250 | HBL3100R6W | HBL3100P6W | HBL3100C6W | HBL3100B6W | BB100N | BB1001W BB1002W | IN3100BF | IN3100BM† |
| | 2P 3W | | | | 480 | HBL3100R7W | HBL3100P7W | HBL3100C7W | HBL3100B7W | BB100N | BB1001W BB1002W | IN3100BF | IN3100BM† |
| | 3P 4W | | | | 125/250 | HBL4100R12W | HBL4100P12W | HBL4100C12W | HBL4100B12W | BB100N | BB1001W BB1002W | IN4100CF† | IN4100CM |
| | 3P 4W | | | | 3Ø250 | HBL4100R9W | HBL4100P9W | HBL4100C9W | HBL4100B9W | BB100N | BB1001W BB1002W | IN4100DF | IN4100DM |
| | 3P 4W | | | | 3Ø480 | HBL4100R7W | HBL4100P7W | HBL4100C7W | HBL4100B7W | BB100N | BB1001W BB1002W | IN4100DF | IN4100DM |
| | 3P 4W | | | | 3Ø600 | HBL4100R5W | HBL4100P5W | HBL4100C5W | HBL4100B5W | BB100N | BB1001W BB1002W | IN4100DF | IN4100DM |
| | 4P 5W | | | | 3ØY120/208 | HBL5100R9W | HBL5100P9W | HBL5100C9W | HBL5100B9W | BB100N | BB1001W BB1002W | IN5100EF | IN5100EM |
| | 4P 5W | | | | 3ØY277/480 | HBL5100R7W | HBL5100P7W | HBL5100C7W | HBL5100B7W | BB100N | BB1001W BB1002W | IN5100EF | IN5100EM |
| | 4P 5W | | | | 3ØY347/600 | HBL5100R5W | HBL5100P5W | HBL5100C5W | HBL5100B5W | BB100N | BB1001W BB1002W | IN5100EF | IN5100EM |
| 125 | 2P 3W | | | | 220-240 | HBL3125R6W | HBL3125P6W | HBL3125C6W | HBL3125B6W | BB100N | BB1001W BB1002W | IN3100BFS † | IN3100BMS † |
| | 3P 4W | | | | 380-415 | HBL4125R6W | HBL4125P6W | HBL4125C6W | HBL4125B6W | BB100N | BB1001W BB1002W | IN4100DFS | IN4100DMS |
| | 4P 5W | | | | 220/380 240/415 | HBL5125R6W | HBL5125P6W | HBL5125C6W | HBL5125B6W | BB100N | BB1001W BB1002W | IN5100EFS | IN5100EMS |

Notes: All 63A and all 125A devices have pilot pins or contacts.

See page E-6, E-7 for accessories. See page E-8, E-9 for product dimensions. See page E-10, E-11 for product specifications. Closure caps purchased separately, see page E-7.

† Consult factory.