

Sure Signal®



46060

- Designed for cable installers and communications technicians for testing four-pair data/voice cable links terminated with standard, modular eight-position RJ45-style jacks.
- Simplest tester available for identifying common wiring faults such as shorts, opens and miswires.
- Diagnosis can be completed at one end.
- Sequentially-lighting LEDs correspond to each wire allowing easier diagnosis of miswires than testers that check pairs.
- Can test more wiring configurations than other testers due to sequential wiremap testing.
- Shielded test ports allow extra versatility to test shielded and screened twisted pair.
- Optional patch cords allow the Sure Signal to be used as a coax tester, eliminating the need for a second tester.
- Optional remote unit can be used to check patch cords for wiring errors.
- Optional Accessory Kit includes two RJ45 patch cords, two RJ45 to BNC adapter cords, two RJ45 to RJ11 snap-in adapters and one BNC plug to BNC plug adapter.
- Battery operated (9V not included).
- Lifetime limited warranty.

| CAT. NO. | UPC NO. | DESCRIPTION |
|----------|---------|-------------|
|----------|---------|-------------|

| | | |
|-------|-------|---|
| 46060 | 46060 | Sure Signal Line Verifier and Patch Cord Tester |
| 46070 | 46070 | R Sure Signal Remote |
| 45276 | 45276 | R Carrying Case |
| 46065 | 46065 | R Sure Signal Accessory Kit |
| CSIO | 60381 | R Modular Adapter cable |

Wiremap Tester



468

- Quickly identifies opens, shorts, reversals and transposed pairs.
- Economical tester includes all the basic functions.
- Connecting the receiver unit automatically activates the test process.
- Sequencing red and green LEDs provide fast, accurate and simple-to-understand results.
- Alerts the technician if connected to an active circuit without harming the unit.
- Connect any eight-position modular plug to the appropriate jack on the transmitter and a sweeping tone signal is applied to all pairs.
- At the far end of the cable, use any Tempo inductive amplifier (probe) to locate the corresponding plug or jack.
- Battery operated (9V not included).

| CAT. NO. | UPC NO. | DESCRIPTION |
|----------|---------|-------------|
|----------|---------|-------------|

| | | |
|------|-------|--|
| 468 | 08661 | Wiremap Tester |
| 468C | 60382 | R Carrying Case for the Wiremap Tester |
| 468T | 60379 | R Transmitter |
| 468R | 60380 | R Receiver |
| CSIO | 60381 | R Modular Adapter Cable |

Coaxial Cable Tester



45055

- Provides quick verification of opens or shorts in either the conductor or the shield of coax cable.
- Simple one-button operation provides pass/fail indication.
- Remote terminator allows testing of cables before or after installation.
- Clear red/green LED indication of short or open conditions.
- Standard BNC- and F-type female connectors.
- Battery operated (9V included).
- Lifetime limited warranty.

| CAT. NO. | UPC NO. | DESCRIPTION |
|----------|---------|-------------|
|----------|---------|-------------|

| | | |
|-------|-------|----------------------|
| 45055 | 45055 | Coaxial Cable Tester |
|-------|-------|----------------------|