

## 5.0 INSTALLATION NOTES AND ASSEMBLY INSTRUCTIONS

- 5.1 Using a 301-037 security tool (sold separately), loosen (**do not remove**) the security screw.
- 5.2 The security tool is for a standard 5/32" button head screw generally used on the framework of the phone booths.
- 5.3 Separate the cover assembly from the backplate assembly by pulling the bottom of the cover forward and pushing up. The backplate assembly is designed to be mounted on any flat vertical surface. Four mounting holes are provided.
- 5.4 Run the inside station wire through the backplate assembly and terminate the RJ11C terminal block located on the backplate.
- 5.5 The use of a gas tube station protector is recommended. The station ground should not exceed 50 ohms.
- 5.6 Install the instruction card kit using a 5/16" nut driver.
- 5.7 Plug the modular line cord from the cover assembly into the RJ11C terminal block.
- 5.8 Dress the line cable away from the security screw and install the cover assembly by placing the two tabs into the two corresponding slots. Secure the cover assembly by tightening the security screw.

### \*\*\*\*\*WARNING\*\*\*\*\*

- A. **Never install telephone wiring during a lightning storm.**
- B. **Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.**
- C. **Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.**
- D. **Use caution when installing or modifying telephone lines.**

CEECO  
Communication Equipment & Engineering Company  
PROPRIETARY

